THE MACHINE 300





















EASY INSTRUCTIONS FOR USE

- 1. Remove dies #2 and #3 from the machine. Lay them so die #2 is facing up. Put the shell, with the edges facing down into the groove in die #2.
- 2. Then lay the artwork on top of the shell, with the illustration facing up, followed by the clear plastic shield (mylar).
- 3. Turn the silver pin on die #1 to the right.
- 4. Place the die in the machine. Line up the top of your illustration to the silver pin on die #1 as shown below.



- 5. Pull the handle down until it will go no further. Use of extreme force is not necessary.
- 6. Take dies #2 and #3 out of the machine. Lay them so die #3 is facing up.
- 7. Lay the pinned back with the outside of the pin facing down in die #3. Turn the silver pin on die #1 to the left. Put the die back into the machine lining up the top of the pinned back to the silver pin on die #1 as shown below.



- 8. Pull the handle down until it will go no further. Use of extreme force is not necessary.
- 9. Take the dies out of the machine. The button is now finished.